


ATENCIÓN: Schuller recomienda que utilice los balancines suministrados en la instalación de este colgante.



Para ver la ficha técnica de producto completa, puede usar el siguiente código QR:



Para cualquier duda técnica póngase en contacto con nuestro Departamento Técnico.
 Estamos a su servicio en nuestro email mperez@schuller.es o en nuestro teléfono 961 601 051

Rev.04.26

MODIFICAR LOS LÍMITES DE LONGITUD DEL SUBE Y BAJA

Paso 1.- Sacar la polea del florón (está sujeta sólo con imanes)

ACORTAR A LA POSICIÓN MÍNIMA

Paso 1.- Girar con la llave allen la polea. Mientras gira escuchará varios clics de los engranajes. El cable se va acortando.

ALARGAR A LA POSICIÓN MÁXIMA

-IMPORTANTE-

Usar guantes de protección

Recomendamos hacer este proceso entre 2 personas.

Paso 1.- Girar con la llave Allen la polea un sólo clic, presionar y mantener presionada la lengüeta de liberación de freno.

Paso 2.- Estirar sacando el cable de la polea hasta la longitud deseada, soltar la lengüeta de freno.


Paso 3.- Recoger cable con la llave allen. Probar la altura estirada antes de terminar de recogerlo todo.

NOTA:

Al estirar la lámpara su altura a 180cm, también se alarga la mínima 80cm.



ATTENTION: Schuller recommends to use included special screws when installing this pendant lamp.



You may use the following QR code to view the complete technical data sheet of the product:



If you have any technical questions, please do not hesitate to contact our technical Department.
We are at your disposal in our email: export@schuller.es

CHANGE THE LENGTH LIMITS FOR THE UP AND DOWN

Step 1.- Remove the pulley from the finial (it is held in place by magnets only)

SHORTEN TO THE MINIMUM POSITION

Step 1.- Turn the pulley using the Allen key. As you turn it, you will hear several clicks from the gears. The cable will shorten.

EXTEND TO THE MAXIMUM POSITION

-IMPORTANT-

Wear protective gloves

We recommend that two people carry out this process.

Step 1.- Turn the pulley using the Allen key just one click, press and hold the brake release tab.

Step 2.- Extend the cable by pulling it out of the pulley to the desired length, then release the brake lever.

Step 3.- Reel in the cable using the Allen key. Check the extended height before finishing reeling it all in.

NOTE:

When extending the lamp to a height of 180cm, the minimum height is also extended to 80cm.

